

Installation Instructions-Privacy or Passage - Lever

Passage/Private Door Prep.

1

2-3/8" or 2-3/4"
1" Dia. Edge Bore
2-1/8" Dia. Bore
1/8" Deep
2-1/4"
1"

Dummy Set

Surface Mounted, No bore Hole

Passage/Privacy Set

2

Remember to Install Plastic Alignment Device

Attach Faceplate

Install Latch, Rotate Nose Bolt As Required.

Inside Of Door

Inside Privacy Pin

AFTER LOCK HAS BEEN INSTALLED Tighten Set Screws with Allen Wrench

Installation Instructions-Privacy or Passage - Lever

Passage/Private Door Prep.

1

2-3/8" or 2-3/4"
1" Dia. Edge Bore
2-1/8" Dia. Bore
1/8" Deep
2-1/4"
1"

Dummy Set

Surface Mounted, No bore Hole

Passage/Privacy Set

2

Remember to Install Plastic Alignment Device

Attach Faceplate

Install Latch, Rotate Nose Bolt As Required.

Inside Of Door

Inside Privacy Pin

AFTER LOCK HAS BEEN INSTALLED Tighten Set Screws with Allen Wrench

EMTEK
ASSA ABLOY

304 PASS PRIV LE Rev. 01/2018